



ANN ARBOR FIRE DEPARTMENT

Standard Operation Procedure - 3.12 Air Monitoring



AIR MONITORING

Effective: August 20, 2021
Scheduled Review: August 20, 2024
Approved: Fire Chief Mike Kennedy

I. PURPOSE

The purpose of this SOP is to provide a procedure regarding air monitoring equipment.

II. RESPONSIBILITY

The Logistics Division has ultimate responsibility for record keeping, repair, and maintenance. The Logistics Division may delegate certain responsibilities or solicit assistance as needed.

III. GENERAL USAGE

Whenever air monitoring is required such as carbon monoxide incidents, natural gas leaks, confined space emergencies, hazardous materials incidents, overhaul phase of structure fires, or work being performed in an IDLH atmosphere, monitors are to be fresh air started and zeroed. All structural fires require air quality monitoring for CO and HCN after being brought “under control” and prior to SCBA required usage is lifted.

IV. HYDROGEN CYANIDE

The short-term exposure limit for hydrogen cyanide (HCN) recommended by the National Institute for Occupational Safety and Health is 4.7 ppm and is also the ceiling of exposure limit recommended by the American Conference of Industrial Hygienists. The Occupational Safety and Health Administration still uses 10 ppm as its short-term exposure limit, but the Environmental Protection Agency lists 10 ppm as creating possible adverse medical impacts in as little as 30 minutes. HCN is estimated to be 26 to 35 times more toxic than carbon monoxide. For personnel to operate without SCBA during overhaul, readings of HCN must be below 4 ppm. Immediately Dangerous to Life and Health (IDLH) for HCN is 50 ppm.

V. QRAE 3

Each station has a QRAE 3, 4-gas air monitor with the following sensors: oxygen (O₂), methane (CH₄), hydrogen sulfide (H₂S), and carbon monoxide (CO).

A. Operation

- i. To turn the QRAE 3 on, press and hold the [MODE] key until the audible alarm stops and then release.
- ii. During startup, the battery, buzzer, vibration alarm, and LEDs are tested, and then the QRAE 3 performs self-testing of its other functions. When the main measurement screen appears, the QRAE 3 is ready for calibration or use.

Note: If the battery is completely empty, then the display briefly shows the message “Battery Discharged!” and the QRAE 3 shuts off. You should charge or replace the battery before turning it on again.

Note: If “Zero At Start,” “Must Calibrate” or “Must Bump” is set, you will be prompted to perform the appropriate calibration before using the instrument.



ANN ARBOR FIRE DEPARTMENT

Standard Operation Procedure - 3.12 Air Monitoring



B. Zero and Fresh Air Calibration

- i. The QRAE 3 should be zero-calibrated in clean air with 20.9% oxygen or with a cylinder of clean zero air. In Programming Mode, press [MODE] to select "Multi Zero." Press [Y/+] to select it. Then press [Y/+] to start a Fresh Air calibration for the listed sensors. All are fresh-air calibrated at once. During calibration, the screen says, "Calibrating." When done, each sensor is shown, accompanied by the word "Pass."
- ii. The QRAE 3 shall be examined and tested during Saturday morning apparatus checks. Should any problem be noted, the company officer shall contact the Logistics Division.
- iii. Station officers shall ensure that their station's QRAE 3 is calibrated monthly at Station 1.

C. Turning the QRAE 3 Off

- i. Press and hold [MODE]. A 5-second countdown to shutoff begins. Continue pressing on the key for the entire shutoff process. Otherwise, the shutoff operation is canceled and the QRAE 3 continues normal operation.
- ii. When the countdown ends and the screen displays "Unit Off!" release your finger from the [MODE] key. The QRAE 3 is now off.

D. Testing the Alarm - Under normal-operation mode and non-alarm conditions, the buzzer, vibration alarm, LED, and backlight can be tested anytime by pressing [Y/+] once. If any alarm does not respond, check the Alarm Settings in Programming Mode to make sure all alarms are enabled. If any alarms are enabled but are not functional, do not use the instrument

VI. BW Clip

The BW Clip is a portable, single-gas detector manufactured by BW Technologies by Honeywell (BW). The BW Clip has a carbon monoxide sensor and is a simple to use single gas monitor that once it is turned to the "ON" position will remain "ON" for two years or until the battery exhausts itself. The detector does not need calibration. However, zeroing the detector weekly is recommended. Each basic life support licensed vehicle has one of these detectors attached to the primary EMS bag. The user manual is available via [this link](#). The BW Clip should be mainly maintenance free. In the event a sensor or battery has a problem, contact the Logistics Division.

VII. ToxiRAE Pro

The ToxiRAE Pro is a single gas monitor for hydrogen cyanide. It is kept on the battalion chief vehicle.

A. Operation

- i. To turn the ToxiRAE 3 on, press and hold [MODE] for 3 seconds. During startup, the battery, buzzer, vibration alarm, and LEDs are tested, and then the ToxiRAE Pro performs self-testing of its functions. When the main measurement screen appears, the ToxiRAE Pro is ready for calibration or use.
- ii. The ToxiRAE Pro's user interface consists of the display, four LED lights, an alarm buzzer, and two keys, [MODE] and [Y/+].



ANN ARBOR FIRE DEPARTMENT

Standard Operation Procedure - 3.12 Air Monitoring



The LCD displays real-time reading in specified measurement units, sensor type, alarm type (when in alarm, including cal. or bump overdue), Man Down status, battery status, datalog (if on), and radio and connection quality (if available). Turning the ToxiRAE 3 Off

- iii. Turning The ToxiRAE Pro Off, press and hold [MODE]. A 5-second countdown to shutoff begins. You must continue pressing on the key for the entire shutoff process. If you remove your finger from the key during the countdown, the shutoff operation is canceled and the ToxiRAE Pro continues normal operation. When the countdown beeps stop and you see “Unit Off,” release your finger from the [MODE] key. The ToxiRAE Pro is now off.

B. Calibration

The ToxiRAE Pro can be automatically bump tested and calibrated using the AutoRAE 2 Test and Calibration Station (refer to its User’s Guide for instructions). Manually calibrate using a fixed-flow regulator (flow rate between 0.5 and 1.0 liters per minute) and the supplied special calibration adapter that covers the gas inlet:

- i. To begin calibration, connect the zero air or calibration gas cylinder, flow regulator, and calibration adapter to the ToxiRAE Pro.
- ii. Enter Programming Mode by pressing and holding [MODE] and [Y/+] simultaneously until the password screen appears.
- iii. Input the 4-digit password. (The default password is “0000.” If you do not know the password, highlight and select “OK.”) Then follow the instructions for zero calibration and span calibration.
- iv. Important! After a bump test or calibration, remove the calibration adapter to ensure correct readings.

C. Zero (Fresh Air) Calibration

The ToxiRAE Pro should be zero-calibrated in clean air with 20.9% oxygen. If the ambient air has impurities, a cylinder of clean zero air should be used for zero calibration. With the ToxiRAE Pro in Programming Mode and “Zero Calib” highlighted:

- i. Press [Y/+] . “Apply zero gas...” is displayed.
- ii. Start the flow of the zero gas, if used, and press [Y/+] to start the fresh air or zero calibration.
- iii. The screen says, “Zeroing...” and shows the countdown.
- iv. When done, it says, “Zero is done! Reading = X” (this reading should be 0.0 ppm or very close to it for toxic gas sensors, and 20.9% Vol. for an oxygen sensor).
- v. “Span Calib” is highlighted.
- vi. Shut off the flow of zero air (if used).
- vii. Remove the calibration adapter.